Camera Control Basics

- Have one hand on each side of the camera controls.
- Start on slow speeds for zooming and panning.
- Leave on auto focus. We leave that on unless you are panning. Always make sure you are in focus before your shot goes live.
- Keep camera settings the same from camera to camera.

Power cord for on/off is behind this corner.

The Iris knob adds light to your video shot or takes it away. If a shot is looking too dark, you can help the lights person by adding light. Typically, we leave it on auto unless certain tones or shots look off.

Gives you a visual layout for what camera settings are. Keep camera settings the same from camera to camera.

Allows you to jump from camera to camera. The lit up camera with a green light is connected and on. Hold the button to turn a camera off. Hold AND touch the screen off.

The focus knob: Turn to adjust your camera focus. Normally, leave the auto button on and use the auto focus.

This is the main "zoom" feature. You can go tight and wide with the zoom.

Use this knob to control the speed of the zoom.

This knob effects the speed of pan and tilt.

Controller- This controls your pan and tilt. It has a 360 degree movement. Use the controller button (trigger) as a zoom option.